

HEAVY-DUTY

GATE CLOSER

Pressed Steel – Galvanized


INSTALLATION INSTRUCTIONS

Ensure post hinges and frame hinges are positioned approximately 8" from the top and bottom of the gate post with top hinge pin pointing down and bottom hinge pin pointing up.

NOTE: 2" spacing required between gate post and gate frame

STEP 1

Position Heavy-Duty Gate Closer around posts and secure in position with 3/8" carriage bolts.



Gate Post Hinge	Gate Frame Hinge	Heavy-Duty Part No.
2-3/8"	1-3/8"	017432
2-7/8"	1-5/8"	017503
2-7/8"	1-7/8"	017504

For more information, contact our Customer Service Department:
1-888-MH-FENCE (toll-free)
P.O. Box 365, La Habra, CA 90633
e-mail: info@fenceonline.com • www.fenceonline.com

